Data sheet Issue 17/12/2024

# **BYK-381**

Polyacrylate-based surface additive for aqueous coatings and adhesives to improve leveling. Improves the leveling and substrate wetting in aqueous and radiation-curable printing inks and overprint varnishes.

### **Product data**

# Composition

Solution of ionic polyacrylate copolymer

#### **Typical properties**

The values indicated in this data sheet describe typical properties and do not constitute specification limits.

Density (20 °C): 1.03 g/ml Active substance: 52 %

Solvent: di-propylene glycol monomethyl

ether Flash point: 75 °C

# **Applications**

# **Coatings industry**

#### **Special features and benefits**

The additive improves leveling and prevents surface defects such as craters and pinholes.

### **Recommended use**

It is recommended for all aqueous coatings.

#### **Recommended levels**

0.1–1 % additive (as supplied) based on the total formulation.

The above recommended levels can be used for orientation. The optimum dosage should be determined by application-related test series.

# Incorporation and processing instructions

The additive can be incorporated during any stage of the production process, including post-addition.

### **Adhesives and sealants**

### **Special features and benefits**

The additive improves leveling and prevents surface defects such as craters and pinholes.

#### Recommended use

It is recommended for all aqueous adhesives.

Data sheet Issue 17/12/2024

#### **Recommended levels**

0.1–1 % additive (as supplied) based on the total formulation.

The above recommended levels can be used for orientation. The optimum dosage should be determined by application-related test series.

#### Incorporation and processing instructions

The additive can be incorporated during any stage of the production process, including post-addition.

### **Printing inks**

#### Special features and benefits

The additive improves leveling and substrate wetting and prevents surface defects such as craters and pinholes.

#### Recommended use

It is recommended for aqueous and radiation-curable printing inks and overprint varnishes.

#### **Recommended levels**

0.1–1 % additive (as supplied) based on the total formulation.

The above recommended levels can be used for orientation. The optimum dosage should be determined by application-related test series.

### Incorporation and processing instructions

The additive can be incorporated during any stage of the production process, including post-addition.





#### BYK-Chemie GmbH

Abelstraße 45 46483 Wesel Germany Tel +49 281 670-0 info@byk.com www.byk.com ANTI-TERRA®, AQUACER®, AQUAMAT®, AQUATIX®, BENTOLITE®, BYK®, BYK-AQUAGEL®, BYK®-DYNWET®, BYK MAX®, BYK® SILCLEAN®, BYKANOL®, BYKCARE®, BYKETOL®, BYKOHLAST®, BYKOPLAST®, BYKUMEN®, CARBOBYK®, CERACOL®, CERAFAK®, CERAFLOUR®, CERAMAT®, CERATIX®, CLAYTONE®, CLOISITE®, DISPERBYK®, DISPERPLAST®, FULACOLOR®, FULCAT®, GARAMITE®, GELWHITE®, HORDAMER®, LACTIMON®, LAPONITE®, NANOBYK®, OPTIBENT®, OPTIGEL®, PURABYK®, RECYCLOBYK®, RHEOBYK®, SCONA®, SILBYK®, TIXOGEL® and VISCOBYK® are registered trademarks of the BYK group.

The information contained herein is based on our current knowledge and experience. No warranties, guarantees and/or assurances of any kind, either express or implied, including warranties of merchantability or fitness for a particular purpose, are made regarding any products mentioned herein and data or information set forth, or that such products, data or information may be used without infringing intellectual property rights of third parties. Any information about suitability, use or application of the products is non-binding and does not constitute a commitment regarding the products' properties, use or application. Contractual terms and conditions, in particular agreed product specifications, always take precedence. We recommend that you test our products in preliminary trials to determine their suitability for your intended purpose prior to use. We reserve the right to make any changes and to update the information herein without notice.