

CLAYTONE-APA V XR

Vegan, powdered rheology additive based on organically modified bentonite (organophilic phyllosilicate) for use in personal care applications to increase viscosity, provide thixotropic flow behavior and suspend pigments and particles in medium to high polar solvents.

Gamma irradiation sterilized version of CLAYTONE-APA V.

Product data

Composition

Organophilic phyllosilicate (INCI: Stearalkonium Bentonite)

Vegan

Typical properties

The values indicated in this data sheet describe typical properties and do not constitute specification limits.

Bulk density:	150–250 kg/m ³
Water content:	max. 3 %
Particle size distribution D50:	10 µm
Sieve passing (440 Mesh/32 µm):	min. 90 %
Total viable count:	< 100 cfu/g
Color:	light cream
Delivery form:	powder

Storage and transportation

CLAYTONE-APA V XR should be transported and stored dry in unopened original packaging at temperatures between 0 °C and 30 °C.

Applications

Personal care

Special features and benefits

CLAYTONE-APA V XR is used in cosmetic products to increase viscosity, provide thixotropic flow behavior, and suspend pigments and particles. It swells and disperses easily and may be used to stabilize water-in-oil emulsion systems. Suitable solvents are all medium to high polar organic fluid systems, such as ethyl acetate, butyl acetate, isopropyl myristate, C12-15 alkyl benzoate, or glycerin. Additionally, CLAYTONE-APA V XR is compatible with surfactants and emulsifiers.

Recommended use

Creams and lotions	
Sunscreen products	
Antiperspirants/deos	
Liquid makeup	
Lipsticks	
Cream eye shadows	
Nail polishes	

 especially recommended  recommended

Recommended levels

1–10 % additive (as supplied) based upon the total formulation, depending on the application.

The above recommended levels can be used for orientation. The optimum dosage should be determined by application-related test series.

Incorporation and processing instructions

CLAYTONE-APA V XR is effective in a wide range of organic fluid systems and has no processing temperature requirements. For maximum efficiency, CLAYTONE-APA V XR must be incorporated with very high shear, e. g. dissolver, rotor-stator system, or homogenizer.

It is recommended to incorporate CLAYTONE-APA V XR into the solvent phase using a concentrated pre-gel. This is the preferred option for nail lacquers to obtain ultra-high gloss. In some cases, CLAYTONE-APA V XR can also be incorporated directly as a powder into the oil phase (in-situ incorporation).

Pre-gels can be prepared by the following procedure:

1. Add the organic solvent to the dispersion vessel.
2. Slowly add CLAYTONE-APA V XR (10 % by weight of total pre-gel) to mixer under agitation.
3. Mix at very high shear for approx. 15 minutes.
4. Incorporate the other formulation ingredients into the gel.



**Your local
contact**

BYK-Chemie GmbH
Abelstraße 45
46483 Wesel
Germany
Tel +49 281 670-0
Fax +49 281 65735

info@byk.com
www.byk.com

ADD-MAX®, ADD-VANCE®, ANTI-TERRA®, AQUACER®, AQUAMAT®, AQUATIX®, BENTOLITE®, BYK®, BYK-AQUAGEL®, BYK®-DYNWET®, BYK-MAX®, BYK®-SILCLEAN®, BYKANOL®, BYKCARE®, BYKETOL®, BYKJET®, BYKO2BLOCK®, BYKONITE®, BYKOPLAST®, BYKUMEN®, CARBOBYK®, CERACOL®, CERAFAX®, CERAFLOUR®, CERAMAT®, CERATIX®, CLAYTONE®, CLOISITE®, DISPERBYK®, DISPERPLAST®, FULACOLOR®, FULCAT®, GARAMITE®, GELWHITE®, HORDAMER®, LACTIMON®, LAPONITE®, MINERPOL®, NANOBYK®, OPTIBENT®, OPTIFLO®, OPTIGEL®, POLYAD®, PRIEX®, PURABYK®, PURE THIX®, RECYCLOBLEND®, RECYCLOBYK®, RECYCLOSSORB®, RECYCLOSTAB®, RHEOBYK®, RHEOCIN®, RHEOTIX®, SCONA®, SILBYK®, TIXOGEL® and VISCOBYK® are registered trademarks of the BYK group.

The information herein is based on our present knowledge and experience. The information merely describes the properties of our products but no guarantee of properties in the legal sense shall be implied. We recommend testing our products as to their suitability for your envisaged purpose prior to use. No warranties of any kind, either express or implied, including warranties of merchantability or fitness for a particular purpose, are made regarding any products mentioned herein and data or information set forth, or that such products, data or information may be used without infringing intellectual property rights of third parties. We reserve the right to make any changes according to technological progress or further developments.

This issue replaces all previous versions.