

ABIL® Soft AF 100

Silicone based conditioning agent for improved body and volume of hair

- Strongly substantive to hair and skin keratin due to the aminofunctional groups.
- For conditioners and shampoos (especially clear ones).
- Easy to use, self-emulsifying.
- Liquid, high active.

Personal Care

INCI Name (CTFA Name)

Methoxy PEG/PPG-7/3 Aminopropyl Dimethicone

Chemical	and	physical	properties
(not part	of sp	ecificati	ons)

Appearance	liquid
Туре	aminofunctional siloxane

Properties

ABIL® Soft AF 100 conditions and volumizes fine hair. Hair treated with ABIL® Soft AF 100 is easier to comb and smoother. These benefits are especially evident on chemically treated hair.

ABIL® Soft AF 100 improves the substantivity of skin care emulsions.

ABIL® Soft AF 100 is a liquid and easy to handle. During preparation, the self emulsifying property is beneficial as it forms a fine dispersed emulsion in water.

ABIL® Soft AF 100 contains hydrophilic groups. This makes it more compatible with aqueous systems when compared to Amodimethicone. Since ABIL® Soft AF 100 is easy to solubilize with surfactants, it can be used in *clear* shampoo or shower bath formulations.

Application

ABIL® Soft AF 100 is used in


- Conditioners and emulsions
- Shampoos and skin cleansing formulations

ABIL* Soft AF 100 improves the manageability of the hair. The loss of volume, which is common when using traditional hair conditioners, can be avoided by using ABIL* Soft AF 100.

Figure 1 shows the result of a sensory test on hair swatches. Cetrimonium Chloride (CTAC = VARISOFT* 300) provides in a standard conditioner formulation (0.5 % Ceteareth-25, 2 % Cetyl Alcohol, 2 % conditioning agent, pH 4) a very good wet combability. It is known that the influence of CTAC on the volume in this application is poor. By combining CTAC with ABIL* Soft AF 100 the judgement of the volume effect will be significantly improved.

In this test Amodimethicone shows no positive influence on body/volume. "Control" marks the test formulation without conditioning additive.

The combination of ABIL® Soft AF 100 with cationic conditioning additives is especially advantageous. By combining it with an alkyltrimethyl ammonium chloride like VARISOFT® 300 (Cetrimonium Chloride) or VARISOFT® BT 85 (Behentrimonium Chloride) an optimum of conditioning effect is obtained.



Standard conditioner formulation:

- 0.5 % Ceteareth-25
- 2.0 % Cetyl Alcohol
- 2.0 % conditioning agent

pH 4

Fig. 1: Results of a sensory test with conditioning rinse on hair swatches.

Suggested usage concentration

0.3 - 4.0 % ABIL® Soft AF 100 in conditioners.

0.1 - 2.0 % ABIL® Soft AF 100 in shampoos and skin cleansing preparations.

0.2 - 1.0 % ABIL* Soft AF 100 in skin care emulsions.

Packaging

200 kg drum

Hazardous goods classification

Information concerning

- classification and labeling according to regulations for transport and for dangerous substances
- protective measures for storage and handling
- measures in accidents and fires
- toxicity and ecological effects

is given in our safety material data sheets.

Processing hints

For conditioners and emulsions:

Add ABIL® Soft AF 100 to the oil phase.

For shampoo formulations:

Solubilize ABIL® Soft AF 100 with anionic surfactant(s), water insoluble ingredients and solubilizers, if necessary, and stir until it is homogeneous. Add the water and then the amphoteric surfactants (e.g. TEGO® Betain or REWODERM®), water soluble ingredients, thickeners (e.g. ANTIL®, REWODERM® LIS 80) and pearlizers (e.g. TEGO® Pearl), if wanted.

Guide Line Formulations

In-Shower Hair and Body Conditioner (O/W emulsion) SG 877/3	
Phase A	
ABIL® Soft AF 100	0.5 %
TEGO® Alkanol 16 (Cetyl Alcohol)	2.0 %
VARISOFT® BT 85 Pellets (Behentrimonium Chloride)	1.0 %
Phase B	
Glycerin	2.0 %
Water	94.2 %
Perfume	0.2 %
Preservatives	q.s.

Preparation:

Heat phases A and B separately to 80 °C (the VARISOFT® BT 85 Pellets must be melted). Mix B with A and cool while stirring. Homogenize at 65 °C. Add the perfume below 45 °C.

Clear Conditioning Shampoo WA 156/1/4	
Sodium Laureth Sulfate (28 %)	32.0 %
ABIL® Soft AF 100	0.4 %
Perfume	0.5 %
Water	54.6 %
TEGO® Betain F 50	10.0 %
(Cocamidopropyl Betaine)	
VARISOFT® PATC	2.0 %
(Palmitamidopropyltrimonium Chloride)	
NaCl	0.5 %
Preservatives	q.s.
Preparation : Mix the ingredients in the given order.	

IMIX the ingredients in the given order.

Conditioning Shampoo for fine Hair WA 156/1/5	
Sodium Laureth Sulfate (28 %)	28.6 %
Perfume	0.3 %
ABIL® Soft AF 100	0.2 %
Water	56.3 %
TEGO® Betain F 50 (Cocamidopropyl Betaine)	5.3 %
REWOTERIC® AM C (Sodium Cocoamphoacetate)	5.3 %
ANTIL® 171 (PEG-18 Glyceryl Oleate/Cocoate)	3.0 %
NaCl	1.0 %
Preservatives	q.s.
Preparation: Mix the ingredients in the given order.	

Styling Cream (W/O emulsion) WA 156/5/13	
Phase A	
ABIL® EM 90 (Cetyl PEG/PPG–10/1 Dimethicone)	2.0 %
Mineral Oil	2.0 %
ABIL® OSW 5 (Cyclopentasiloxane; Dimethiconol)	8.0 %
ABIL® Soft AF 100	0.5 %
TEGOSOFT® CT (Caprylic/Capric Triglceride)	3.0 %
Hydrogenated Castor Wax	0.5 %
Cyclopentasiloxane	4.0 %
Perfume	0.3 %
Phase B	
Water	79.2 %
NaCl	0.5 %

Preparation:

Heat phases A and B to 70 °C. Stir B into A and cool while stirring. Homogenize at 65 °C. Add the perfume below 45 °C.

Hair Tip Fluid (O/W emulsion) WA 156/4/2	
Phase A	
TEGINACID® C	0.5 %
(Ceteareth-25)	
ABIL® Soft AF 100	0.3 %
TEGO® Alkanol 16	2.0 %
(Cetyl alcohol)	
TEGIN® M Pellets	1.0 %
(Glyceryl Stearate)	
ABIL® OSW 5 (Cyclopentasiloxane; Dimethiconol)	7.5 %
Perfume	0.3 %
Phase B	
Water	88.4 %
Preservatives	q.s.

Preparation:

Heat phases A and B to 70 °C. Mix A into B and homogenize at 65 °C. Add the perfume below 45 °C.

E 06/08

This information and all further technical advice is based on our present knowledge and experience. However, it implies no liability or other legal responsibility on our part, including with regard to existing third party intellectual property rights, especially patent rights. In particular, no warranty, whether express or implied, or guarantee of product properties in the legal sense is intended or implied. We reserve the right to make any changes according to technological progress or further developments.

The customer is not released from the obligation to conduct careful inspection and testing of incoming goods. Performance of the product described herein should be verified by testing, which should be carried out only by qualified experts in the sole responsibility of a customer. Reference to trade names used by other companies is neither a recommendation, nor does it imply that similar products could not be used. (Status: April, 2008)

Evonik Industries AG Goldschmidtstraße 100 45127 Essen, Germany P.O. BOX 45116 Essen PHONE +49 201 173-2854 FAX +49 201 173-1828 personal-care@evonik.com www.evonik.com/personal-care

