Data sheet Issue 11/2023

# **CLAYTONE-MPZ V**

Vegan, powdered rheology additive based on organically modified natural bentonite (organophilic phyllosilicate) for use in personal care applications to increase viscosity, provide thixotropic flow behavior and suspend pigments and particles in medium to high polar solvents.

#### **Product data**

Composition

Organophilic phyllosilicate (INCI: Stearalkonium Bentonite)

#### **Typical properties**

The values indicated in this data sheet describe typical properties and do not constitute specification limits.

Bulk density: 220–330 kg/m³ Water content: max. 3 % Particle size distribution D50: 12 µm Sieve passing (200 mesh/74 µm): min. 98 % Color: light cream powder

#### **Storage and transportation**

CLAYTONE-MPZ V should be transported and stored dry in unopened, original packaging at temperatures between 0 °C and 30 °C.

## **Applications**

#### **Personal Care**

#### **Special features and benefits**

CLAYTONE-MPZ V is used in cosmetic products to increase viscosity, provide thixotropic flow behavior, and suspend pigments and particles. It may be used to stabilize water-in-oil emulsion systems and is designed to impart a high degree of gelling efficiency over a wide range of medium to high polar fluids. Suitable solvents are all medium to high polar organic fluid systems, such as butyl acetate, ethyl acetate, C12-15 alkyl benzoate, or isopropyl myristate. Additionally, CLAYTONE-MPZ V is compatible with surfactants and emulsifiers.

Data sheet Issue 11/2023

#### Recommended use

Creams and lotions	
Sun care products	
Antiperspirants/deos	
Liquid makeup	
Lipsticks	
Cream eye shadows	
Nail polishes	
especially recommended recommended	

### **Recommended levels**

1–8 % additive (as supplied) based upon the total formulation, depending on the application.

The above recommended levels can be used for orientation. The optimum dosage should be determined by application-related test series.

#### Incorporation and processing instructions

CLAYTONE-MPZ V is effective in a wide range of organic fluid systems and has no processing temperature requirements. For maximum efficiency, CLAYTONE-MPZ V requires a polar activator and very high shear, e. g. dissolver, rotor-stator system, or homogenizer.

Suggested polar activators are:

- Propylene carbonate/H<sub>2</sub>O (95:5) 15–40 %\*
- Ethanol/H<sub>2</sub>O (95:5) 15–60 % \*
- \*based on weight of CLAYTONE-MPZ V

It is recommended to incorporate CLAYTONE-MPZ V into the solvent phase using a concentrated pre-gel. This is the preferred option for nail lacquers to obtain ultra-high gloss. In some cases, CLAYTONE-MPZ V can also be incorporated directly as a powder into the oil phase (in-situ incorporation).

Pre-gels can be prepared by the following procedure:

- 1. Add the organic solvent to the dispersion vessel.
- 2. Slowly add CLAYTONE-MPZ V (5–10 % by weight of total pre-gel) to mixer under agitation.
- 3. Mix at very high shear for approx. 15 minutes.
- 4. Add the polar activator.
- 5. Mix at very high shear for approx. 15 minutes.
- 6. Incorporate the other formulation ingredients into the gel.









info@byk.com www.byk.com ADD-MAX®, ADD-VANCE®, ANTI-TERRA®, AQUACER®, AQUAMAT®, AQUATIX®, BENTOLITE®, BYK®, BYK®-AQUAGEL®, BYK®-DYNWET®, BYK-MAX®, BYK®-SILCLEAN®, BYKANOL®, BYKCARE®, BYKETOL®, BYKIET®, BYKO2BLOCK®, BYKONITE®, BYKOPLAST®, BYKUMEN®, CARBOBYK®, CERACOL®, CERAFAK®, CERAFLOUR®, CERAMAT®, CERATIX®, CLAYTONE®, CLOISITE®, DISPERBYK®, DISPERPLAST®, FULACOLOR®, FULCAT®, GARAMITE®, GELWHITE®, HORDAMER®, LACTIMON®, LAPONITE®, MINIERPOL®, NANOBYK®, OPTIBENT®, OPTIFLO®, OPTIGEL®, POLYAD®, PRIEX®, PURABYK®, PURE THIX®, RECYCLOBLEND®, RECYCLOSSORB®, RECYCLOSTAB®, RHEOBYK®, RHEOCIN®, RHEOTIX®, SCONA®, SILBYK®, TIXOGEL® and VISCOBYK® are registered trademarks of the BYK group.

The information herein is based on our present knowledge and experience. The information merely describes the properties of our products but no guarantee of properties in the legal sense shall be implied. We recommend testing our products as to their suitability for your envisaged purpose prior to use. No warranties of any kind, either express or implied, including warranties of merchantability or fitness for a particular purpose, are made regarding any products mentioned herein and data or information set forth, or that such products, data or information may be used without infringing intellectual property rights of third parties. We reserve the right to make any changes according to technological progress or further developments.

This issue replaces all previous versions.